\rightarrow S Drive Actuator

- > Transmits horizontal rotation of drive shaft to vertical movement of lockbar
- > Easy to position on side panel
- > Lockbar is held in position when drawer is opened
- > Unique adjustment cam design allows for easy movement of lock interface for accurate pin alignment; use a 4 mm (5/32") hex key to adjust
- > Material: Steel; Cam: Zinc die-cast, unfinished Linkage arm: Plastic; Color: black

Timberline No.	Item No.
AC-120	237.67.310